

EAR IMPRESSION INSTRUCTIONS

1.- Our custom in-ear monitors require a full shell earpiece impression. All full shell impressions must include the full helix, crus of the helix, tragus and antitragus.

2.- A full impression is required of each ear. (Be sure to examine the ear canal for any obtrusions or inflammation.)

It's very important that impressions must be taken just past the second bend of the ear canal.

3.- The impressions must be made of high viscosity silicone impression material.

4.- The impression must be taken with the customer's mouth open. It ensures a more secure fit and a better seal while the artist is singing, playing an instrument or talking.

For that purpose we recommend to use a 1 inch bite block during the impression process. This will help to stabilize the mouth position and is more comfortable for the customer. It also ensures that there is no jaw movement while the material is curing.

5.- Once you have earpiece impressions, please mail boxed impressions to:

INTERNATIONAL

Advanced Ears
101 N McColl Rd. Unit 8 Ste. 3590
McAllen, TX 78501

Be sure that your name and personal contact information is included with your impressions. Please contact your local dealer if you have questions or any concern regarding these instructions.

IMPORTANT: All impressions must possess all key points described or it could result in rejected impressions

If you have any questions or comments, please do not hesitate to contact your dealer.

If you are unsure whether your earpieces impressions fill our needs, please send us pictures of your impression at the following: info@advancedears.com. This is highly recommended for international customers where there is no dealer available. Remember that pictures should be from multiple angles in order to see all ear shape and canal details.

- 1.- Ear canal
- 2.- 1st Bend
- 3.- 2nd Bend
- 4.- Tragus
- 5.- Shell
- 6.- Antitragus
- 7.- Helix

All impressions requires extra material outside of the ear above the tragus & antitragus

